
Quick Reference Card 7 Day Digital Timer 1531





Setting the Time and Day of the Week:

Press and hold for 2 seconds.

Time of day will start flashing.

Press Or To adjust time setting.
Once time is set, release button.
Flashing will stop after 5 seconds and day of the week will begin flashing.

Press Or To select day of the week.
Once set, wait for flashing to stop.

Operating Heater in Manual Mode:

Press To turn the heater on.
The operation Indicator will light up.

Press To turn the heater off.
The operation Indicator light will go out.

Programming Heater Starting Time: Press To begin timer programming. The timer memory location number starts flashing. Continue to press button until the desired memory location 1, 2 or 3 is visible. Press To adjust start time setting. Once start time is set, release button. Flashing will stop after 5 seconds and day of the week will begin flashing. To select day of the week. Press Heater will start on the time and day selected. Once set, wait for flashing to stop. To program the other 2 memory locations, repeat the above 3 steps for each memory location. Recalling or cancelling a programmed start time: Press To cycle through memory locations. Any one of the 3 memory locations can be activated each time the button is pressed. After selecting the memory location you desire, you will be able to change the day and time setting if desired be repeating steps 1,2 and 3 above.

repeatedly until no memory location number is visible on timer display.

Webasto Product N.A., Inc.

Press

15083 North Road Fenton, MI 48430

Technical Assistance: 1-800-555-4518 (USA)

1-800-667-8900 (CAN)

www.techwebasto.com