Operating Instructions for MCI 7-Day Electronic Timer

MCI 7-Da	y Electronic Timer	Thermosystems	
3 5 6 DISPLAY PROG	1 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 12:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:00 10:0	 Time of day / preset time Heater active indicator (Timer active indicator (y Clock AM/PM indicator (Day of the week indicator Function / setting button 	green). ellow). (red). ors (red).
General	The 7-Day Electronic Timer provides full control of heater operation in either manual or timed modes. The timer allows for 1 preset start time setting once within a 24 hour period on any 1 day up to 7 days in advance. The current time and weekday must be programmed.		
Clock Programming	Press and hold button 'PROG', release both buttons simultaned programming mode. Day indica	ously to activate	DISPLAY PROG MIN +
	Press button 'DAY \rightarrow ' to select	day of week.	MIN +
	Press button 'SET' to activate time setting mode.		ON OFF HEATER SET
	Press button 'HR +' to select co	prrect hour.	ON OFF TIMER HR +
	Press button 'MIN +' to select o	orrect minute.	MIN +
	Press button 'SET' to end clock If 'SET' button is not depressed programming function will end a	within 15 seconds,	ON OFF HEATER SET

Timer Programming	Press and hold button 'PROG', depress 'HR +' briefly and release both buttons simultaneously to activate programming mode. The yellow timer indicator (3) will flash.		
	Press button 'DAY \rightarrow ' to select desired day of week.		
	Press button 'SET' to activate time setting mode.		
	Press button 'HR +' or 'MIN +" to select heater start time. If the dip switch setting is in the AM/PM mode, the red PM HR^+ MR^+		
	Press button 'SET' to end timer programming mode. If 'SET' button is not depressed within 15 seconds, programming function will end automatically.		
Manual Operation	To manually switch the heater on, press the 'ON OFF HEATER' button. The green heater 'active' indicator (2) will respond. Press button a second time to turn the heater off.		
Timed Operation	Press the 'ON OFF TIMER' button to activate or deactivate the timed start of heater mode. Whenever the 'ON OFF TIMER' button is pressed, the current timer setting will be visible on the display for a few seconds. When the timer mode is active, the yellow timer indicator (3) will respond. The heater will automatically switch on upon reaching the programmed start time.		
Timer Duration	With the ignition off, and the heater is switched on manually or automatically, it will stay on for a duration of 1 hour or until the 'ON OFF HEATER' button is pressed. With the ignition on (bus in operation), the heater will run and cycle continuously until the ignition key is turned off.		
Display Stand By Mode	The timer display will be visible whenever the ignition is on or any of the timer function buttons (6) are pressed. If the ignition is off, the display will be visible for 30 seconds.		
Image: Constraint of the systemConstraint of the systemConstr			
and the second	Technical Assistance: 1-800-667-8900		